

An environment rich in beneficial bacteria supports your well being.

The BioLogic nourishes your indoor environment with a repetitive flow of Enviro-Biotics™ that cleans Air, Surfaces and Objects, especially in those hard to reach areas.

BIOLOGIC

QUICK START GUIDE



betterair



Programming

On/Off button

1. Press the led button to turn ON the unit.
2. Press the button for two seconds to turn OFF the unit.

Status light

1. Green light: working mode
2. Blue light: pause
3. Red light: low liquid
4. Yellow light: low battery

When USB charger is plugged, the LED indicator will flash 3 times.
When red light flashes, this is an indication of both low liquid and low battery.

Position of the BioLogic

Your **BioLogic** should be located out of the reach of young children or pets. It is not advised to place the BioLogic near an open door or a window that leads outdoors in order to obtain maximum coverage indoors.

The most common place recommended for placing your **BioLogic** is in the bedroom, as that is where people generally spend most of their time at home plus that's where dust mite allergens are most common.



CAUTION: Do not place directly under lights or other heat sources over 100 degrees. Damage to the BioLogic may occur.

Cartridge Replacement

1. The refill must be replaced when empty, approximately every 3 months.



IMPORTANT: Always turn power off when removing and replacing cartridge. Also, power must be turned off before moving the BioLogic.

Equipment and Accessories



- BioLogic
- BioLogic refill
- USB cable
- User manual

WARNING

The BioLogic should be used only with the power pack provided by the manufacturer.

Specifications

Dimensions

72mm (l) x 72mm (w) x 184mm (h)

Weight

320 gr

Power Supply

Working voltage: 3.7v

Input - USB charger 5v

Standby Time: Up to 13 days

Battery Capacity: 4000 mAh

Coverage: 0-20 sqm

Bottle capacity: 75 ml

Working temp: 2 - 43°C

Safety Precautions

Turn off and unplug the unit before moving it.

Warranty is only valid with the use of Enviro-Biotics™.

Do not immerse in or place the BioLogic near water, sinks or bathtubs.

WARNING

KEEP OUT OF REACH OF CHILDREN

Avoid swallowing and eye contact.

If swallowed - drink 1-2 glasses of water.

If in eyes - Flush with water.

Store in a cool dry place.



betterair

Contact Us

(844) 447-7624

www.Better-Air.com

support@betterairus.com

© 2015 Better Air North America LLC.
All rights reserved